



Power Supplies

PUREGAS offers a selection of Power Supplies, Fuse Panels and Boost Transformers to make sure that you have the required power available for your Pipe & Flow Panels, Monitoring System and Air Dryers.

PVD48VT - 48 VDC Power Supply



When 48 VDC power is not available, plug in this converter to a nearby 110 VAC outlet.

PVDP5 - 48 VDC Rectifier / Fuse Panel



- 48 VDC power rectifier
- 5 circuit distribution panel using industry standard GMT fuses
- Front panel OK/FAIL & BLOWN FUSE LED indicators
- Low profile 1.75" chassis

PVDP20 - 48 VDC Fuse Panel



- 20 circuits for the distribution of 48 VDC power, each individually protected by a GMT style telecommunication fuse
- Alarm circuits are provided to indicate alarm conditions when faults occur
- Normal operation LED's are provided to indicate the status of each bus in the panel
- 2 isolated groups (Busses) of 10 GMT fuses each (15 Amps/GMT position)
- Can operate at 200 Amps of output current per panel (100 Amps per Bus)

P010709 - Boost Transformer



Can be used to boost insufficient incoming AC Voltage to the recommended range required to operate your Air Dryer most efficiently.